

How to Install Kiravans Handbrake Lowering Kit

Suitable for: VW Transporter T5, T6, T6.1

Time for the job: 10-15 minutes

Tools required:

- Electrical tape
- 13mm Socket Spanner
- Socket spanner extension piece
- Flat head screwdriver
- M5 Allen key

1. Before working on the handbrake: put the van in gear & chock your wheels.
2. Remove handbrake cover by pushing away the small tab beneath the front of the handle. Use a flat screwdriver.
3. Remove the OEM trim by lifting up and sliding over the handbrake.
4. Remove 2 x nuts using a 13mm socket. An extension piece will help with the front nut.
5. Lift away the handbrake. You may need to loosen off the handbrake cable tension beforehand.
6. Fit the supplied self-grip U-channel onto the middle ridge.
7. Fit the clear split tube over your brake cable. Apply 3 pieces of electrical tape to stop it coming off.
8. Attach the new bracket to your handbrake using supplied nuts, bolts and washers. Use a 13mm spanner with an M5 allen key.
9. Present the bracket to the original hand brake mounting. Ensure that the cable and clear tube are both in place.
10. Fix the new bracket in place using original nuts and 13mm socket.
11. Tighten up the brake cable such that your handbrake operates as before. If you are unsure about the correct tension then please consult an auto mechanic.
12. Fit the new trim plastic. It will click into place as the locators find their position.
13. Re-apply the original handbrake cover. The left face fits outside the edge of your new trim box.
14. Check that the handbrake cover clip is back in its original locating position.